




Industrial-grade Wireless Smart Multi-Sensor Device GS1 User Guide


This manual book is a general guidance for all types of our Industrial-grade GS1 devices. Some features which are marked with asterisk are available for specific versions. Please refer to related instructions according to the version you purchased.

【Introduction】

1. Appearance Introduction



2. Screen Icons Introduction



3. Device Operations

Switch On

Press and hold the power button for 3 seconds until the screen lights up. Release the button and the device is now on.

Switch Off

Press and hold the power button for 3 seconds until the screen is off. The device is now off.

Device Setup Mode

With the device switched on, press and hold the menu button for 3 seconds. Release the button until the **AP** icon flashes on the screen.

Manual Data Synchronisation

With the device switched on, press the power button once to trigger a manual data sync. The icon will flash while the data is being transferred. You can also hear the voice guidance.

Toggle Screen Readings

Press the menu button once to toggle between the internal sensor readings and external probe readings and sensing data simultaneously.

Switch On/Off Voice Guide

Double press the menu to enable or disable the voice guide. This will also refresh the last sensing data.

Toggle Celsius or Fahrenheit

Double press the power button to toggle between displaying Celsius or Fahrenheit. This will also refresh the last sensing data.

Display Backlight

Pressing either of the buttons will switch on the display backlight for a short time. Pressing both the two buttons at the same time will keep the backlight alight constantly. Pressing another time will switch off the backlight.

Reset to Default Settings

Switch the device off, then press and hold the menu button and power buttons together for at least 8 seconds. Release the buttons when you hear the voice guidance “ The device will now reset” .

IMPORTANT ALL STORED DATA WILL BE LOST IF YOU RESET YOUR DEVICE TO DEFAULT SETTINGS!
REMEMBER TO SYNCHRONISE THE SENSING DATA TO THE UBIBOT® IoT PLATFORM OR EXPORT THE DATA TO YOUR COMPUTER BEFORE RESETTING IT.

【App INSTALLATION】

1. App Installation

Download the App from www.ubibot.io/setup
Or Search for “UbiBot” on the App Store or Google Play.




2. PC Offline Tools Installation


Download the tool from www.ubibot.io/setup
Please note that this tool is for professional use only to export offline data to PC.

3. WiFi Setup

STEP1. Launch the App, register an account if needed and log in. On the home screen click the “+” to add your device. Scan the QR code on the front side of the device, or manually enter the serial number.




Add your device



Scan the QR code

STEP2. Put your device into device setup mode (see p.02). The AP icon should flash on the screen.


STEP3. The device will ask you to enter your WiFi password. Check that the correct SSID is selected and enter the password. The App will now prompt you to go to your phone settings screen. Change to the UbiBot-xxx network and return to the App.



STEP4. The device will now complete the setup process, register with the server and do the initial data sync. Your phone will automatically switch back to its normal WiFi network. If the connection failed, please repeat the process and ensure you entered the correct WiFi details in step 3.

4. Mobile Data Setup (For AL4G1RS model)

STEP1. Insert your SIM card according to the direction shown (notch facing lower right), plug USB power and switch on your device.



STEP2. Launch the App, register an account if needed and log in. On the home screen click the “+” to add your device. Scan the QR code on the front side of the device, or manually enter the serial number. Now press the menu button for 3 seconds to enter device setup mode. (the AP icon flashes on the screen).

STEP3. Follow the onscreen guidance to complete the setup.

5. ETH network Setup(suits AETH1RS version)

STEP1. Plug in the Ethernet cable into the port on the left side of the device.

STEP2. Launch the app, register if needed and log in. On the main screen, click the “+” to add your device. Scan the QR code on front side of the device, or manually enter the serial number. Follow the onscreen guidance to complete the setup.

Making Sense of Your World



【ERROR CODES】

01 System Protection

Please follow the instructions to properly configure the device. Unconfigured devices will revert to system protection mode to save power.

02 WiFi Connection Failed

Please refer to the Troubleshooting section 3 on page 9.

03 Failed to Connect to Server

Please refer to the Common Questions at www.ubibot.io/category/faqs

04 Device Activation Failed

Please refer to the Troubleshooting section 1 on page 8.

05 Data Save Failure

This can happen when there is a power disruption while saving data when the power is disrupted while data is being saved.

06 Incorrect Data Format

This can happen when there is a power disruption while saving data.

07 Data Sync Failed

Please refer to the Troubleshooting section 3 on page 9.

08 No SIM Card Found

Please check the SIM card is correctly inserted.

09 Mobile Data Network Failure

Please check your SIM card is set up correctly and has been activated.

【TECHNICAL SPECIFICATIONS】

	WiFi, 2.4GHz, channels 1-13
	Flame resistant ABS + PC
	Built-in 3000mAh lithium battery
	Type-C, DC5V/2A or 12V/1A power supply
	115mm x 90mm x 55mm
	Built-in Memory:300,000 sensing data
	Supports Micro SIM card* (15mm x 12mm x 0.8mm)
	Supports Ethernet cable*
	Optimal working conditions: -20°C to 60°C, 10% to 90%RH

*Communication mode depending on the specific model purchased.

【TROUBLESHOOTING】

1. Device setup failure when using the UbiBot App

There are several factors that can affect the setup process. The followings are common issues:

- WiFi frequency: The Device can only connect to 2.4GHz networks, channels 1-13.
- WiFi password: Go through the device setup again (p.02) and ensure that you have set the correct WiFi password for the network.
- WiFi security type: The Device supports OPEN, WEP, or WPA/WPA2 types.
- WiFi channel width: Make sure it is set to 20MHz or "Auto".
- Internet connection: Make sure your device's WiFi router has a working Internet connection (for instance, try to access www.ubibot.io using a mobile connected to the same WiFi).
- Low battery power: WiFi uses a lot of power. Your device may be able to power on but may not have enough power for the WiFi. Please charge the device.

⑦Signal strength: Make sure you have a good connection with WiFi, 3G/4G or Ethernet.

⑧Please make sure the device has entered WiFi setup mode.

For direct problem diagnosis, please use the PC Offline Tools to go through the setup process and contact us with the response error code in Tools->Get Device Last Error. This can help us to remotely diagnose.

2. Failure to setup via Ethernet cable:

- Please check if the Ethernet cable is plugged correctly.
- Please check if the Ethernet cable is in good condition.
- Please check if the network has access to the internet.
- Please check if the batteries are too flat to setup.

If all the above conditions are excluded, but you still can not active the device, please check whether the network rejects DHCP(automatic IP allocation); Or, you can also try to re-plug the Ethernet cable and go through the setup process again (p6).

3. Failure to Sync Data. Please check the following:

- With the device swithced on, press the power button once to trigger a manual data sync. You can hear "sync completed" after the data being transferred. If it says "sync failed", try the next steps.
- Check that the device has sufficient battery power for the WiFi to work. WiFi takes a lot of power -- the device may be on, but unable to connect to the WiFi. Please check the battery icon on the screen. Recharge the device before it runs out of the power.
- Make sure your device's WiFi router has a working Internet connection (for instance, try to access www.ubibot.io using a mobile connected to the same WiFi).
- If you are using mobile data, check that your SIM card is activated.

4.Can I Use the Device without a Network Connection? How do I Access the Data?

The device will continue working without a network connection and can store up to 300,000 readings in its memory. Real-time readings are displayed on screen and you can access the data in the following ways:

- Move the device to an area where there is a WiFi connection which the device can connect to. Press the button to trigger a manual data sync. You can hear "sync completed" after the data being transferred. You can now take the device back to the measurement location (Recommended).
- Use your mobile phone and enable Internet Connection Sharing. This can work well when your devices are installed in an area with limited or no WiFi coverage.
- Use a Windows laptop and the Micro USB cable to connect to the device manually. You can now perform a data export to your computer using the PC Offline Tools.
- Set it up with a mobile data card* . Once you are in range of the network, press the power button once to sync all data with the IoT platform.

5.WiFi Connection Problems. Please refer to the list of potential issues above.

If your WiFi password has changed, or if you move the device to a new WiFi environment, you need to go through the device setup again (p.02).

6. Why are my device Temperature readings not accurate?

The measured temperature may be affected by several factors, thus the device may temporarily show inaccurate temperatures during and after the initial setup. Please visit www.ubibot.io/category/faqs/ to view the specific causes and corresponding solutions.

For any other problems, please visit www.ubibot.io/category/faqs. Alternatively, email customer support at support@ubibot.io to get assistance.

【PRODUCT CARE】

- Please always follow the instructions contained in this manual.
- Always mount the device on a stable surface.
- Keep away from acidic, oxidising, flammable or explosive substances.
- When handling the device, avoid using excessive force and never use sharp instruments to try and open it.

【WARRANTY INFORMATION】

- This device is warranted to be free of defects in materials and workmanship for a period of up to one year from the original purchase date. This warranty does not cover damage caused by normal wear, misuse, abuse or incorrect repair. To claim under this limited warranty and to obtain warranty service, email UbiBot® Customer Support at support@ubibot.io to obtain instructions on how to pack and ship the product back to us.
- The following situations will not be covered by the warranty:

- Issues arising after the warranty period has ended
- Malfunction or damage caused by improper or not operating the device according to the instructions.
- Damage occurring from operating device outside the recommended temperature and humidity range, damage from contact with water, damage from applying excessive force to the device or any cables and connectors.
- Natural wear and aging of materials.
- Failure or damage caused by unauthorized removal of the product.
- We are only liable for faults due to manufacturing or design. We are not responsible for damage caused by Force Majeure or acts of God.

【WARRANTY CARD】

Thank you for buying the UbiBot GS1. If you have any problems and wish to claim under the limited warranty, first contact our customer service team using the email address on the back of this book. If Customer Service asks you to return you product to us, please complete the following details and include this form in the package.

Product Details	
Product Name	
Product ID	
Product Serial No.	
Date of Purchase	
Online Purchase Store	
Customer Details	
Name	
Phone	
Address	
Email	

【REPAIR HISTORY】

	Problems Description	Reason for Problems	Repair Description
First Repair			
	Date of Repair:		Repaired by:
Second Repair			
	Date of Repair:		Repaired by:

Only to be completed by UbiBot technicians